



## Assembly Instruction For E20286-20

1. Put rubber washers(B) into metal(A), then secured metal(A) by tube(C).

2. Put square crystal(D) into metal(A), tube(C), then secured tube(C) by finial(E).

