



Installation Instructions Model E20751-NWD

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box.
3. Run the canopy, wire, and pan through glass to have glass resting on pan before installing.
4. Adjust wire length to desired mounting height, and tighten strain relief screws to secure.
5. Wire fixture to wires in outlet box. Green wire is for Ground.

This fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer. Below is a list of recommended dimmers:

- Lutron MACL-153M
- Lutron DVL-153P
- Lutron SCL-153P
- Leviton IPL06-10Z
- Leviton 6674-POW

Due to the inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.

