



Installation Instructions

Model E21401-81PC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box
3. Run the canopy, wire, and pan through glass to have glass resting on pan before installing.
4. Carefully remove packaging from fixture.
5. Wire fixture to wires in outlet box. Green wire is for Ground.
6. Install fixture to bracket and tighten cap nuts so that the fixture meets the ceiling.
7. Hang crystals per diagram.
8. Install maximum 40 watt G9 Xenon bulbs into sockets.

Xenon bulbs get very hot and may burn you. Always make sure bulbs are off for a minimum of 10 minutes before handling.

