



Installation Instructions

Model E21406-81PC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box.
3. Carefully remove packaging from fixture.
4. Run the canopy, wire, and pan through glass to have glass resting on pan before installing.
5. Adjust wire length to desired mounting height using push pin strain relief.
6. Wire fixture to wires in outlet box. Green wire is for Ground.
7. Install fixture to bracket and tighten screws at the ends of the canopy to secure.
8. Hang crystals per diagram.
9. Install maximum 40 watt G9 Xenon bulbs into sockets.

Xenon bulbs get very hot and may burn you. Always make sure bulbs are off for a minimum of 10 minutes before handling.

