



Installation Instructions

Model E22576-PC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box.
3. Calculate desired mounting height and cut wire leaving an additional 10" inside canopy.
4. Insert fiberglass sleeve over 10" wire lead inside canopy.
5. Attach wires to transformer with provided connectors. Make sure additional wire does not sit on top of transformer.
6. Wire fixture to wires in outlet box. Green wire is for Ground.
7. Install fixture to bracket and tighten screws to secure.
8. Install maximum 25 x 10 watts G4 Xenon bulbs into sockets.

(Caution: Xenon bulbs get very hot and may burn you. Always make sure bulbs are off for a minimum of 10 minutes before handling. Fixture may be dimmed using an magnetic low voltage dimmer.)

