



# Contemporary Lighting

Assembly Instruction For E53830  
E53831

Turn breaker off for circuit on outlet where fixture is to be installed.

1. Remove mounting bracket from fixture and install it to electrical box.
2. Wire fixture to wires in outlet box. Green wire is for ground.
3. Install fixture to bracket by turning canopy on screws at the ends of the mounting bracket.
4. Install glass and metal frame to canopy.

This fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer. Below is a list of recommended dimmers:

- Lutron MACL-153M
- Lutron DVL-153P
- Lutron SCL-153P
- Leviton IPL06-10Z
- Leviton 6674-POW

Due to the inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.

