

1. Screw the tube (E) to the tube (F) till tight.
2. Screw the stem (D) to the tube (E) till tight.
3. Screw the stem (C) to the stem (D) till tight.
4. Screw the stem (C1) to the stem (C) till tight.
5. Screw the stem (B) to the stem (C1) till tight.
6. Screw the stem (B1) to the stem (B) till tight.
7. Screw the stem (B2) to the stem (B1) till tight.
8. Thread the nipple (A) to the stem(B2) till tight.
9. Thread the nipple (I) to the coupler (G) and fix it by hex nut (H).
10. Attach the tube (J) , cover (K) , plastic washer (L) , shade (M) , diffuser (N) , shade framer (O) and washer (P) to the nipple (I) in order as the drawing. then fix it by hex nut (Q) and finial (R).

