

1. Fix the wire in junction box at first, then put the Ballast (A) into the junction box, please put the ballast to the beside of the junction box in order to fix the socket assembly easy
2. Put the socket assembly(B) with crossbar to the junction box , the secured by hex nut (C)
3. Place the ceiling pan (D) and Cap(E) to the socket assembly (B), then insert the Jack to the socket (Jack is not included)

