

Contemporary Lighting ™

Assembly Instruction For **EP96085**

TO REMOVE THE SOCKET AND WIRE SET

- 1. Unscrew the Iren screw (F) with Iren key (E) and remove Jack (G) from the wire. <u>Discard the Jack (G).</u>
- 2. Remove glass (A) from the Socket and wire set.
- 3. Unscrew screw (H) with a Philips screw driver.
- 4. Loosen the socket and wire set (S) from nipple set (C). Remove socket and wire set(S). Discard the socket and wire set.

TO ASSEMBLE THE NEW SOCKET AND WIRE SET

- 1. Pass the socket wire (S) through nipple set (C), thread the socket hickey to the nipple. Tighten by turning clockwise.
- 2. Gently tighten the screw (H) with a Philips screw driver. Take care not to over tighten and break the wire insulation.
- 3. Pass wire through the glass shade (A).
- 4. Please refer to the Jack Installation Instruction for instruction on installing the Jack.





