



ET2 Contemporary  
Lighting™

## Assembly Instruction For **EP96087-146**

1. Insert the G9 bulb(I) into socket(H)
2. Through the Socket(H) to the Cap(G)/Smaller Glass(F) /Large Glass(E)  
/Rubber Washer(D)/Metal Washer(C); then secured by Metal Part(B) till tighten
- 3.Thread the Tube(A) to the Metal Part(B) till tighten
- 4.Please see the another page that it is show how to assemble the Jack

