



Assembly Instruction For **ES94507**

1. Screw the stem (D) to the coupler (E) till tight.
2. Screw the stem (C) to the stem (D) till tight.
3. Screw the stem (C1) to the stem (C) till tight.
4. Screw the stem (B) to the stem (C1) till tight.
5. Screw the stem (B1) to the stem (B) till tight.
6. Screw the stem (B2) to the stem (B1) till tight.
7. Thread the nipple (A) to the stem(B2) till tight.
8. Loosed the screws(S) from the nuts (R). Connect the cables (T) to the shade (K) by the screws (S).

Note: If you want to use white pleat shade then need to attach the shade ring to the shade first and fix it by clips on the shade ring.

9. Thread the nipple (H) to the coupler (F) and fix it by hex nut (G).
10. Attach the tube (I), cover (J), plastic washer (L), diffuser (M), plastic washer (N) and metal washer (O) to the nipple (H) then fix it by hex nut (P) and finial (Q).

