




Installation Instructions Model E22248-PC



1. It is recommended the fixture be installed by a qualified licensed electrician.
2. Turn breaker off for circuit on outlet where fixture is to be installed.
3. Remove X bracket from fixture and install to electrical box
4. Mark 4 holes on outer slots of bracket for hollow wall anchors
5. Remove X bracket from outlet
6. Drill 4 x 1/8" holes and insert hollow wall anchors
7. Reinstall X bracket to outlet and secure bracket to ceiling using 4 screws included into hollow wall anchors.
8. Determine mounting height of fixture and adjust wires accordingly.
9. Wire fixture to outlet. Connect white to neutral and green to ground.
10. Install fixture onto X mounting bracket and tighten screws to secure.

Warning! This fixture is supplied with permanently installed LED light engine. The transformer for this light engine is not dimmable. Do not use a dimmer on this fixture or it will damage the transformer. Using a dimmer voids the warranty of the fixture.