




Installation Instructions

Model E22696-18PC

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box
3. Mark 2 holes on outer slots of bracket for hollow wall anchors
4. Remove mounting bracket from outlet
5. Drill 2 x 1/8" holes and insert hollow wall anchors
6. Reinstall mounting bracket to outlet and secure bracket to ceiling using 2 screws included into hollow wall anchors
7. Wire fixture to wires in outlet box. Green wire is for Ground.
8. Install fixture to bracket and tighten 2 screw on end of canopy
9. Install chrome threaded cut onto end of wire
10. Install glass clip onto socket
11. Secure clip with hex nut
12. Install G4 bulb into socket
13. Insert 1 leg of clip into glass followed by remainder 3 clip one at a time and allow glass to seat into chrome threaded cup securely.



FEATURE

- 120V~ 60Hz
- Lamp Type: "Xenon"G4 6× MAX 20W 12V~
- The lamp is for indoor use only