




PRODUCT NAME : Cirque LED Pendant
ITEM NUMBER: E22847-MW

Please consult your electrician for hanging fixture and wiring.



WARNING: WIRES NEED TO BE CONNECTED TO DRIVER FOUND IN CANOPY AND SHOULD NOT CONNECT DIRECTLY TO POWER SOURCE OR A SHORT MIGHT OCCUR.

The fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer.




Below is a list of recommended dimmers:

Lutron MACL-153M
Lutron DVL-153P
Lutron SCL-153P
Leviton IPL06-10Z
Leviton 6674-POW

Due to the inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.


67W LED

IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation




(C)
Body

Locate all hardware & components before discarding packaging




1.)




Step.1: First connect the lamp body (C) parts together by inserting male tab at opening and screw to secure.

2.)




Step.2: Remove Bracket (A) from fixture and install to electrical box.

3.)



Step.3: Wire fixture to wires in outlet box. Install Green wire to Ground Screw.

4.)



Step 4: Adjust wire length to desired hanging height. Install Canopy (B) to Bracket (A) and tighten screws at the ends of canopy to secure.

Cleaning & Care:
Clean with soft cloth and a mild detergent.
Do not use abrasive cleaner.

Cleaning & Care:
Clean with soft cloth and a mild detergent.
Do not use abrasive cleaner.