



Contemporary  
Lighting™

# Installation Instructions Model E23051-09SN

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box (Figure 1)
3. Wire fixture to wires in outlet box. Green wire is for Ground. (Figure 2)
4. Install fixture to back-plate and tighten 2 screws on each side of canopy
5. Adjust to desired height by pulling down or pushing up on lower bar.
6. LEDs are not replaceable. Normal life is 30K – 50K hours

## WARNING!

**THIS FIXTURE IS NOT DIMMABLE. DO NOT USE WITH DIMMER OR DRIVER  
WILL BE DAMAGED!**

