


Contemporary Lighting

PRODUCT NAME: Satellite
ITEM NUMBER: E24284-24

Please consult your electrician for hanging fixture and wiring.



The fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer.

Below is a list of recommended dimmers:

- Lutron MACL-153M
- Lutron DVL-153P
- Lutron SCL-153P
- Leviton IPL06-10Z
- Leviton 6674-POW

Due to inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.

Warning! Wires need to be connected to driver found in canopy and should not be connected directly to power source or a short may occur.

IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation



(A)
Mounting Bracket



(I)
Finial





(J)




(K)

Locate all hardware & components before discarding packaging




1.)

Step.1: Run wire through stems and combine stem lengths to meet desired mounting height.



2.)

Step.2: Using wire terminal block in the canopy, wire the low voltage red/black wire to the driver accordingly! Connect red wire to red, black wire to black.




3.)

Step.3: Remove mounting bracket (G) from fixture and install to electrical box.

Cleaning & Care:

Clean with soft cloth and a mild detergent.
Do not use abrasive cleaner.

IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation



(A)
Mounting Bracket



(I)
Finial




(J)




(K)

Locate all hardware & components before discarding packaging




4.)




Step.4: Wire fixture to wires in outlet box.
Green wire is for Ground. Install fixture to bracket and tighten screws at the ends of the canopy to secure.

5.)



Step.5: Install fixture to bracket and tighten ball nuts (I) on the canopy to secure.

6.)



Step.6: Thread acrylic diffuser (J) to the candle base. Then thread glass (K) over diffuser.

Cleaning & Care:

Clean with soft cloth and a mild detergent.
Do not use abrasive cleaner.

ITEM NUMBER: E24284-24
Acrylic Diffuser & Glass

