


## E30050-11/ E30051-11

### ASSEMBLY INSTRUCTION:

**Carefully remove all parts from the box and remove all plastic coverings.**

- 1) Rotate steel tube (B) connect with part (A) in clockwise direction. Refer to illustration below.
- 2) And the same way to connect tube (C) and part (B).
- 3) Rotate tube (D) together with tube (C).
- 4) Put the ceiling base (E) on the tube (D), and then install the provided washer (F) and ground wire (G). Consult your local hardware store with questions.
- 5) Fix the screw (H) and tube (D) by provided spanner (I).
- 6) Install the glass shade (K) on the lampholder (J) and fix it with part (L) by spanner (O) in clockwise direction. Consult your local electrician with questions.
- 7) Install G9 bulb (N) (max. 40W, provided) to socket.
- 8) And then install the decoration part (M) with ceiling base (E) by provided screw (H).



### WARNING:

Do not use polishes or cleaners on your lamp.  
WIPE CLEAN WITH SOFT DRY CLOTH.