



PRODUCT NAME: Tangent ITEM NUMBER: E20715-82PC

Please consult your electrician for hanging fixture and wiring.




Bulbs (Included): 5 x 4W G9 LED


IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation




Locate all hardware & components before discarding packaging




Cleaning & Care: Clean with soft cloth and a mild detergent. Do not use abrasive cleaner.




Step.1: Fasten the mounting bracket(A) onto the outlet box using two outlet box screws.



Step.2: Wire fixture to wires in outlet box. Green copper wire is for ground. And carefully position all wires inside the outlet box.



Step.3: Adjust the fixture wire to the desired length, Place canopy(B) to mounting bracket(A), then tighten plastic screw(C) back into the hole as shown in diagram.



Step.4: Install Glass(E)/Cap(F) onto socket(D). Install socket ring(G) onto socket (D) by spanner (H). Then install G9 LED bulb (I) into socket(D).