


PRODUCT NAME: Cosmo ITEM NUMBER: E30612

## Please consult your electrician for hanging fixture and wiring.



The fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer.

Below is a list of recommended dimmers:


Lutron MACL-153M Lutron DVL-153P Lutron SCL-153P Leviton IPL06-10Z Leviton 6674-POW

Due to the inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.


WARNING: Wires need to be connected to driver found in canopy and should not be connected directly to power source or a short may occur


LED 2 x 4.5W Bulbs

## IMPORTANT: Turn OFF the power at the main fuse or circuit breaker box before starting installation




## Locate all hardware & components before discarding packaging






Step.1: Remove mounting bracket (A) from back plate (B) and install to electrical box. Use anchor screws provided through mounting bracket (A2) for extra support.



Step.2: Wire fixture to wires in outlet box. Make sure connections are made in accordance with NEC. Install the fixture (C) to the mounting bracket (A) using screws (D) to secure.



Step.3: Place bubble glass sphere (F) into cup and secure using ring (G).

## Cleaning & Care:

Clean with soft cloth and a mild detergent. Do not use abrasive cleaner.