



1. Attach the shade (E) to the big washer (C) then fix it by coupler (B);
2. Attach the harp (D) to the big washer (C) from inside of shade (E) then fix it by screws (A);
3. Thread the nipple (F) to the coupler (L) of harp (D);
4. Attach rubber washer (G), glass diffuser (H) and rubber washer (G1) to nipple (F) then secure by finial (I);

