




Diagram A



1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box
3. Mark where screws at ends of bracket meet the ceiling
4. Remove mounting bracket from ceiling
5. Drill pilot holes using 3/16" where marked
6. Install mounting bracket to outlet box and at anchors to secure bracket at ends.
7. Carefully remove packaging from fixture.
8. Run wire through stems and combine stem lengths to meet desired mounting height.
9. Wire fixture to wires in outlet box. Green wire is for Ground.
10. Install fixture to bracket and tighten screws at the ends of the canopy to secure.

This fixture is designed to dim with a standard Triac forward phase dimmer.

Dimming levels will vary by dimmer. Below is a list of recommended dimmers:

Lutron MACL-153M

Lutron DVL-153P

Lutron SCL-153P

Leviton IPL06-10Z

Leviton 6674-POW

Due to the inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer.

Diagram B




Diagram C

